PLEASE READ AND FOLLOW ALL WARNINGS

FLORIDA PNEUMATIC

FP-759R-2

1/4" ANGLE HEAD DIE GRINDER

Read Operating Instructions
Always become familiar with all the instructions and warnings before operating any power tool.

Always Wear Approved Eye Protection
Impact resistant eye protection should meet or exceed the standards as set forth in the United States ANSI Z87.1, Occupational and Educational Eye and Face Protection. Look for the marking Z87.1 on your eye protection to insure that it is an approved style. For further information, ANSI Z87.1, Occupational and Educational Eye and Face Protection, is available from the American National Standards Institute, Inc., 11 West 42nd Street, New York, NY 10036.

Hearing Protection is Recommended
Hearing protection should be used when the noise level exposure equals or exceeds an 8 hour time-weighted average sound level of 85 dBA. Process noise, reflective surfaces, other tools being operated nearby, all add to the noise level present in your work area. If you are unable to determine your noise level exposure, we recommend the use of hearing protection.

Avoid Prolonged Exposure to Vibration
Tools can vibrate during use. Prolonged exposure to vibration or very repetitive hand and arm movements, can cause injury. Stop using any tool if discomfort, tingling feeling or pain occurs. You should consult your physician before resuming use of the tool.

90 PSIG Maximum
This tool is designed to operate at An air pressure of 90 pounds per square inch gauge pressure (90 PSIG) maximum, at the tool. Use of higher air pressure can, and may cause injury. Also, the use of higher air pressure places the internal components under loads and stresses they were not designed for, causing premature failure. The air supply should be clean and dry, preferably lubricated. For best results, drain the moisture from your compressor daily.

WARNING:
Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to cause cancer, birth defects or reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints
- Crystalline silica from bricks, cement and other masonry products
- Arsenic and chromium from chemically treated lumber

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area and work with approved safety equipment such as those dust masks that are specially designed to filter out microscopic particles.



Description

Florida Pneumatic 1/4" right angle die grinder is designed for grinding and deburring operations in confined areas. This rear exhaust tool features a built-in regulator for convenient speed control and a lock-off lever to prevent accidental starts.

Safety Instructions

The following instructions are furnished as general guidelines for use of your pneumatic tool. They cannot comprehensively cover all possible or conceivable uses of the subject tool. For additional information on the safe use of air tools, we advise you to obtain a copy of ANSI B186.1 Safety Code for Portable Air Tools, available from the following source:

American National Standards Institute, Inc.
11 West 42nd Street
New York, NY 10036.

The use of the word “shall” in the following instructions, indicates that adherence to the particular requirement is necessary to conform to ANSI B186.1.

Tool Application and Usage

Portable tools shall be used only for the purposes intended in their design and within the capacity for which they were intended and rated. It shall be the tool owner’s and/or employer’s responsibility to instruct each operator in the safe use of the tool. Tools shall not be used without guards and safety devices as furnished by the manufacturer. Where an air tool is modified or altered, the modifier shall provide the safeguards to enable it to be safely used in the operations intended and to comply with any applicable provisions as contained in ANSI B186.1.

Tool Installation

Pressure regulators shall be used to limit air pressure to the rated pressure where the supply pressure exceeds the tool’s rated pressure. Air hoses and lines shall be relieved of compressed air before being disconnected or disjointed, unless there is automatic valve closing protection at the joint being separated. Synthetic lubricants which can cause deterioration of elastomer seals shall not be used in air systems of air tools.

Tool Maintenance

It shall be the tool owner’s and/or employer’s responsibility to assure that tools are maintained in a safe operating condition. Tool maintenance and repair shall be performed by authorized, trained, competent personnel. Tools shall be disconnected from their compressed air supply before repairs are attempted. Repairs shall be consistent with the manufacturer’s recommended procedures. Tool, hoses and fittings shall be replaced if unsuitable for safe operation. It shall be the tool owner’s and/or employer’s responsibility to keep required rating markings and warnings on the tool in legible condition.

Florida Pneumatic Air Tools
A Division of Florida Pneumatic Manufacturing Corporation
851 Jupiter Park Lane, Jupiter, Florida 33458
(561) 744-9500 • Fax (561) 575-9134 • Toll Free 1-800-327-9403

Read these instructions carefully before attempting to install, operate or service this Florida Pneumatic product. Failure to comply with the instructions could result in personal injury and/or property damage! Retain these instructions for future reference.

FPMC

FLORIDA PNEUMATIC

FP-759R-2

1/4" ANGLE HEAD DIE GRINDER

Specifications

Collet size	1/4"
Maximum free speed	20,000 RPM
Overall length	6-1/4"
Weight	1¼ lbs.
Average air consumption	4 CFM
Air inlet	1/4" NPT
Recommended hose size	3/8" I.D.
Maximum operating pressure	90 psi



Index No.	Part No.	Description	Qty
1	952-522501	Motor Housing	1
2	940337	Lever Pin	1
3	952-522503	Air Inlet	1
4	952-522504	Throttle Lever	1
5	952-522505	Valve Shaft	1
6	952-522506	Deflector	1
7	9OR00705105	O-Ring (3)	3
8	9522208	Spring	1
9	970109	O-Ring	1
10	952-522510	Valve Screw	1
11	952236	O-Ring	1
12	952212	Rotor Spacer	1
13	9052213	Ball Bearing	2
14	952214	Rear End Plate	1
15	952215	Rotor	1
16	952216	Vane (4)	4
17	930117	Spring Pin (2)	2
18	952218	Cylinder	1
19	952219	Front End Plate	1
20	9030120	Ball Bearing	2
21	9522220	Spring Pin	1
22	952222	Spindle	1
23	9522223	Front Coupling	1
24	951224	Collet	1
25	952225	Collet Nut	1
26	9522226	Front Cap	1
27	952227	Spanner(2)	2
28	956228	Head	1
29	952-522541	Fixed Shaft	1
30	952230	Bevel Gear	1
31	952231	Lock Ring	1
32	930107	O-Ring	1
33	952233	Spindle	1
34	9522236	Busing	1
35	9OR02105105	O-Ring	1
36	952232	Key	1
37	956237	Oil Cap	1
38	952245	Steel Ball	1
39	951540	Safety Bar	1
40	952-522553	Grip	1
41	9522212	Spring	1
42	940145	Steel Ball	1
43	9522240	Throttle Valve	1
46	9522243	Washer	1
51	9522250	Damping Material	1

Florida Pneumatic's Limited Warranty

Florida Pneumatic warrants their tools to be free from defects in material and workmanship for one year from the date of purchase. This warranty does not apply to tools which have been abused, misused, modified or repaired by someone other than Florida Pneumatic or their authorized service centers. If a Florida Pneumatic tool proves defective in material or workmanship within one year after purchase, return it to any authorized service center or Florida Pneumatic freight prepaid. Please enclose your name, address and adequate proof of purchase and a short description of the defect. Florida Pneumatic will, at their option, repair or replace defective tools, free of charge. Repairs or replacements are warranted as described above for the remainder of the original warranty period. Florida Pneumatic's sole liability and your exclusive remedy under this warranty is limited to repair or replacement of the defective tool. There are no other warranties expressed or implied and Florida Pneumatic shall not be liable for incidental, consequential or special damages, or any other damages, costs or expense of repair or replacement as described above.